



Correct Cryogenics, Inc.

15698 Boyle Ave. Fontana, CA 92337

*Ph. (909)355-0923 * Fax (909) 355-0929*

SCHEDULE FOR TANK INSTALL AT UC IRVINE

6/08/15

8:00 AM	ARRIVE AT LOCATION
8:00 – 9:30	DISCONNECT THE CURRENT TANK WITH PRAXAIR SERVICE TECH
9:30 – 11:00	REMOVE AND LOAD THE PRAXAIR TANK ON TRAILER
11:00 – 3:00	SET THE NEW TANK ON THE PAD AND MARK THE HOLES. MOVE THE TANK OFF THE PAD AND CORE THE HOLES AND INSTALL THE STUDS. SET TANK BACK ON THE PAD AND GROUT THE LEGS
3:00 – 4:00	RECONNECT THE EXTENDED FILL LINE

6/09/15

8:00 AM	ARRIVE AT LOCATION
8:00 – 1:00	DO THE FIRST FILL WITH PRAXAIR AND RECONNECT THE TANK TO YOUR CURRENT PIPING
1:00 – 2:00	HAVE 3 RD PARTY INSPECTOR VERIFY THE SYSTEM
2:00	RESTART THIS SYSTEM