Photobonding TM Technology




USHIO Inc.

Bryn Gornick
Application Engineer, Scientific Medical Division
Ushio America Inc.
June 28th, 2017



<us>USHIO Group around the world>



THIS PRESENTATION CONTAINS PROPRIETARY AND CONFIDENTIAL INFORMATION OF USHIO AMERICA, INC. ("UAI"), AND SHALL NOT BE USED, DISCLOSED, OR REPRODUCED, IN WHOLE OR IN PART, FOR ANY PURPOSE OTHER THAN TO EVALUATE A POTENTIAL BUSINESS RELATIONSHIP BETWEEN UAI AND THE INTENDED RECIPIENT OF THIS PRESENTATION, WITHOUT THE PRIOR WRITTEN CONSENT OF UAI. ALL INFORMATION CONTAINED HEREIN IS AND SHALL AT ALL TIMES REMAIN THE PROPERTY OF UAI.

- EXCIMER LAMP -

Excimer Lamp Characteristics






1. Short wavelength

Excimer lamps

2. High efficiency


Light sources for LCD cleaning


- 3. Low heat generation
- 4. Instant ignition
- 5. Lamp installation in arbitral direction
- 6. Mercury free




Xe₂ Excimer lamp







Spectrum of Xe₂ excimer lamp



Surface Activation by Xe₂ Excimer Lamps







Photo excitation and oxidation Substrate





	of 172-nm VUV Light			
166.7	kcal/mol			
Bonding Energ	gy of Various Molecular			
с—с	84.3kcal/mol			
C=C	140.5			
C-H	97.6			
C-F	115.2			
C—CI	76.9			
C-N	63.6			
C-O	76.4			
C=O	190.0			
0-0	32.9			
o=0	117.5			
O—H	109.3			
H—F	134.9			
H—CI	101.9			
N—H	91.9			
Si-O	150.0			

- PHOTOBONDINGTM - (DIRECT BONDING)

Bonding Process and Application









Bonding Mechanism (PDMS / Glass)





XPS Analysis of VUV Activated Surface of PDMS



- ✓ C/Si ratio decrease, and O/Si ratio increase
- ✓ Si-O bond increase


$$\begin{bmatrix}
\mathsf{CH}_3 \\
\mathsf{Si}\text{-}\mathsf{O} \\
\mathsf{CH}_3
\end{bmatrix}_n \xrightarrow{\text{irradiation}} \begin{bmatrix}
\mathsf{OH} \\
\mathsf{Si}\text{-}\mathsf{O} \\
\mathsf{OH}
\end{bmatrix}_n \text{ or } \mathsf{SiO}_2$$

Bonding Test Results



o:Good ∆:Limited

	PDMS	СОР	РММА	Quartz glass
PDMS	0			
СОР	0	0		
РММА		Δ	Δ	
Quartz glass	0		Δ	0



COP-COP




PMMA-PMMA



PDMS-PDMS



PDMS-Glass




PDMS-COP

Features and Applications



- ✓ Adhesive free bonding
- ✓ Low temperature process
- ✓ Small deformation





End of Presentation

